


Pneumatic Tools Steels

Jacksets


10.2 mm shank diameter for riveters
AVC10, AVC12 and AVC13

Brazier head




Ø A (mm)	Rivet head Ø (mm)	Brazier head / part no.
10.2	3	AV1-22C-4
10.2	4	AV1-22C-5
10.2	5	AV1-22C-6
10.2	6	AV1-22C-8
10.2	8	AV1-22C-10

Jackset blank*



Flush head jackset




Ø A (mm)	Ø B (mm)	Soft blank / part no.	Flush head / part no.
10.2	13	AV1-22S-16	—
10.2	16	AV1-22S-20	—
10.2	19	AV1-22S-24	—
10.2	22	AV1-22S-28	—
10.2	25	—	AV1-126D

* Soft blank Jacksets require hardening before use.

Jacksets

12.7 mm shank diameter for riveters AVC26.

Jackset blank*




Ø A (mm)	Ø B (mm)	Part no.
12.7	21	AV24-222S-26
12.7	30	AV24-222S-38

* Soft blank Jacksets require hardening before use.

Scaler Accessories

Scaling chisels for Series 172 and 182



Type	Part no.	Length (mm)
Extra Hard		
1	WF-14F-7	178
1	WF-14F-12	305
2	WF-14B6 1/8	156
2	WF-14B-11 1/2	292
3	WF-14A-6 1/8	156
4	WF-14G-6	152
5	WF-14-7 1/8	181

Scaler attachment (housing) plus set of 19 steel needles – NS11 attachments allow conversion of models 172L, 182L and 182G-EU into needle scalers.



Part no.	Needle housing type	Needle length (mm)	Compatible Ingersoll Rand tool
NS11A	Round	127	172 & 182 Series
NS11A7	Round	178	172 & 182 Series
NS11B7	Rectangular	178	172 & 182 Series
PF2219-K19	Round	Without needle (1)	125-EU

(1) See 127 mm length needles hereunder.

Replacement needle sets (19 needles)

for 172, 182, 125-EU scalers & MC121-NSA scaler attachment

Part no.	Material	Needle length (mm)
NS11-22-19	Steel	127
NS11-122-19	Steel	178
NS11-B22-19	Beryllium copper	127
NS11-S22-19	Stainless steel	127